



CLICK ON PARTS DESCRIPTION TO NAVIGATE TO CORRESPONDING PRODUCT PAGE

**LIST OF PARTS**

\*If part is not clickable, it is either not available or not sold separately.

- |                                 |                               |                             |
|---------------------------------|-------------------------------|-----------------------------|
| 1 Barrel                        | 26 Trigger                    | 51 Sling Swivel             |
| 2 Front Sight                   | 27 Trigger Rivet              | 52 Sling Swivel Screw       |
| 3 Front Sight Screw             | 28 Trigger Pin                | 53 Elastic Spacer           |
| 4 Front Sight Cover             | 29 Trigger Rod Pin            | 54 Trigger Guard            |
| 5 Front Sight Base              | 30 Trigger Rod                | 55 Trigger Guard Plate      |
| 6 Front Sight Base Screw        | 31 Trigger Rod Nut            | 56 -                        |
| 7 -                             | 32 Trigger Spring Washer      | 57 Rear Stock Screw         |
| 8 Rear Sight                    | 33 Trigger Pull Spring        | 58 Magazine Shell           |
| 9 Rear Sight Screw (2x)         | 34 Bolt Guide                 | 59 Magazine Follower        |
| 10 -                            | 35 Bolt                       | 60 Magazine Follower Spring |
| 11 -                            | 36 Extractor                  | 61 Magazine Base            |
| 12 Magazine Housing Insert      | 37 Holder                     | 62 Magazine Plunger         |
| 13 Magazine Housing Insert Pin  | 38 Extractor Spring           | 63 Magazine Plunger Spring  |
| 14 -                            | 39 Safety                     | 64 Magazine Shell           |
| 15 Receiver                     | 40 Bolt Handle                | 65 Magazine Follower        |
| 16 Magazine Housing             | 41 Striker                    | 66 Magazine Follower Spring |
| 17 Magazine Housing Front Screw | 42 Striker Spring             | 67 Adapter Body             |
| 18 Magazine Housing Rear Screw  | 43 Striker Spring Support     | 68 Magazine Shell           |
| 19 Magazine Catch               | 44 Stock                      | 69 Magazine Follower        |
| 20 Magazine Catch Spring        | 45 Butt Plate                 | 70 Magazine Follower Spring |
| 21 Magazine Catch Pin           | 46 Butt Plate Screw (2x)      | 71 Magazine Base            |
| 22 Sear                         | 47 Front Stock Screw          |                             |
| 23 Sear Steel Ball              | 48 Barrel Screw (2x)          |                             |
| 24 Sear Spring                  | 49 Sling Swivel Assembly (2x) |                             |
| 25 Sear Pin                     | 50 Sling Swivel Wood Screw    |                             |