



CLICK ON PARTS DESCRIPTION TO NAVIGATE TO CORRESPONDING PRODUCT PAGE

LIST OF PARTS

**If part is not clickable, it is either not available or not sold separately.*

- | | | |
|-------------------------------|------------------------------|--------------------------------|
| 1 Barrel | 26 Extractor | 51 Fan-shaped Washer |
| 2 Front Sight Base | 27 Extractor Pin | 52 Stock |
| 3 Front Sight Base Screw (3x) | 28 Extractor Spring | 53 Butt Plate |
| 4 Front Sight | 29 Cocking Lever | 54 Butt Stock Screw (2x) |
| 5 Front Sight Screw | 30 Recoil Spring (2x) | 55 Swivel Attachment (2x) |
| 6 Front Sight Cover | 31 Recoil Spring Strut (2x) | 56 Fore-Stock |
| 7 Fore-Stock Fixture | 32 Recoil Spring Carrier | 57 Fore-Stock Screw |
| 8 Rear Sight | 33 Trigger Mechanism Casing | 58 Fore-Stock Lip |
| 9 Rear Sight Screw (2x) | 34 Trigger Safety | 59 Fore-Stock Lip Screw (2x) |
| 10 Receiver | 35 Trigger Safety Pin | 60 Magazine Shell |
| 11 Slide | 36 Trigger Safety Pin Spring | 61 Magazine Plunger |
| 12 Slide Pin | 37 Trigger | 62 Magazine Plunger Spring |
| 13 Barrel Screw (2x) | 38 Trigger Pin | 63 Follower |
| 14 Release Pin | 39 Trigger Spring | 64 Magazine Spring |
| 15 Ejector | 40 Disconnecter | 65 Magazine Base |
| 16 Ejector Pin | 41 Disconnecter Pin | 66 Magazine Shell |
| 17 Casing | 42 Disconnecter Spring | 67 Follower |
| 18 Magazine Housing | 43 Percussion Hammer | 68 Magazine Spring |
| 19 Magazine Catch | 44 Percussion Hammer Spring | 69 Magazine Base |
| 20 Magazine Catch Pin | 45 Hammer Insert (2x) | 70 Magazine Shell |
| 21 Magazine Catch Spring | 46 Hammer Pin | 71 Follower |
| 22 Slide | 47 Trigger Backstop Pin | 72 Magazine Spring |
| 23 Firing Pin | 48 Securing Pin | 73 Magazine Housing Insert |
| 24 Firing Pin Lug | 49 Stock Screw Nut | 74 Magazine Housing Insert Pin |
| 25 Firing Pin Spring | 50 Stock Screw | |