

CLICK ON PART DESCRIPTION TO NAVIGATE TO CORRESPONDING PRODUCT PAGE

- 1 Barrel
- 2 Front Sight
- 3 Front Sight Cover
- 4 Rear Sight Ramp
- 5 Rear Sight Base
- 6 Rivet
- 7 Slide
- 8 Receiver
- 9 Magazine Housing
- 10 Magazine Housing Front Screw
- 11 Magazine Housing Rear Screw
- 12 Magazine Catch
- 13 Magazine Catch Spring
- 14 Magazine Catch Pin
- 15 Sear
- 16 Sear Spring
- 17 Screw
- 18 Washer
- 19 Trigger
- 20 Trigger Pin
- 21 Retaining Ring (2x)
- 22 Roll
- 23 Pin
- 24 Bolt Guide
- 25 Bolt
- 26 Extractor
- 27 Holder
- 28 Extractor Spring

- 29 Safety
- 30 Bolt Handle
- 31 Striker
- 32 Striker Spring
- 33 Striker Spring Support
- 34 Stock
- 35 Butt Plate
- 36 Butt Plate Screw (2x)
- 37 Sling Swivel Assembly
- 38 Sling Swivel Wood Screw
- 39 Sling Swivel
- 40 Sling Swivel Screw
- 41 Elastic Spacer
- 42 Trigger Guard
- 43 Trigger Guard Plate
- 44 Trigger Guard Screw (2x)
- 45 Rear Stock Screw
- 46 Magazine Shell
- 47 Magazine Follower
- 48 Magazine Follower Spring
- 49 Magazine Base
- 50 Magazine Plunger
- 51 Magazine Plunger Spring

- 10 Shot Magazine:
- 52 Magazine Shell
 - 53 Magazine Follower
 - 54 Magazine Follower Spring

*If part is not clickable, it is either not available or not sold separately.

ILLUSTRATION AND LIST OF PARTS

