

CLICK ON PART DESCRIPTION TO NAVIGATE TO CORRESPONDING PRODUCT PAGE

- |                               |  |                          |
|-------------------------------|--|--------------------------|
| 1 Barrel                      | 29 Bolt Stop Pin                           | 56 Spring Washer         |
| 2 Rear Sight                  | 30 Pin                                     | 57 Stock                 |
| 3 Front Sight                 | 31 Ejector                                 | 58 Butt Plate            |
| 4 Front Sight Base            | 32 Ejector Spring                          | 59 Butt Plate Screw      |
| 5 Insert                      | 33 Sear                                    | 60 Swivel Wood Screw     |
| 6 Screw                       | 34 Sear Stop                               | 61 Sling Swivel          |
| 7 Spring Washer               | 35 Sear Stop Spring                        | 62 Swivel Screw          |
| 8 Front Sight Detent          | 36 Sear Pin                                | 63 Swivel Washer         |
| 9 Detent Spring               | 37 Trigger Housing                         | 64 Sling Swivel Assy     |
| 10 Pin, Front Sight Detent    | 38 Trigger                                 | 65 Trigger guard         |
| 11 Front Sight Cover          | 39 Trigger Lever                           | 66 Magazine Catch        |
| 12 Receiver                   | 40 Trigger Pin                             | 67 Magazine Catch Spring |
| 13 Bolt                       | 41 -                                       | 68 Rear Spacer           |
| 14 Bolt Handle                | 42 Adjusting Screw, Set -Trigger           | 69 Frame Screw, Front    |
| 15 Extractor                  | 43 Set-Trigger Lever                       | 70 Frame Screw, Rear     |
| 16 Extractor Collar           | 44 Set-Trigger Lever Spring                | 71 Magazine Shell        |
| 17 Firing Pin                 | 45 Pin                                     | 72 Follower              |
| 18 Firing Pin Spring          | 46 Retaining Ring (2x)                     | 73 Magazine Spring       |
| 19 Firing Pin Spring Retainer | 47 Adjusting Screw (B)                     | 74 Magazine Base Lock    |
| 20 Bolt Handle Catch          | 48 Spring, Trigger Pull                    | 75 Magazine Floor Base   |
| 21 Bolt Sleeve                | 49 Adjusting Screw, Trigger Pull (A)       | 76 Fore End Band         |
| 22 Pin, Firing Pin            | 50 Locking Nut                             | 77 Fore End Band Screw   |
| 23 Safety                     | 51 Adjusting Screw, Trigger Overtravel (C) | 78 Fore End Nut          |
| 24 Safety Spring              | 52 Locking Nut                             | 79 Trigger Spring        |
| 25 Bolt Handle Catch Plate    | 53 Nylon Pin (2x)                          |                          |
| 26 Bolt Handle Catch Post     | 54 Trigger Mechanism                       |                          |
| 27 Bolt Stop                  | 55 Screw                                   |                          |
| 28 Bolt Stop Spring           |  |                          |

\*If part is not clickable, it is either not available or not sold separately.

ILLUSTRATION AND LIST OF PARTS

