

CLICK ON PART DESCRIPTION TO NAVIGATE TO CORRESPONDING PRODUCT PAGE

- 1 Barrel
- 2 Rear Sight
- 3 Front Sight
- 4 Front Sight Base
- 5 Front Sight Base Screw 05
- 6 Front Sight Base Screw 03
- 7 Rear Sight Base Screw
- 8 Front Sight Detent
- 9 Detent Spring
- 10 Pin, Front Sight Detent
- 11 Front Sight Cover
- 12 Receiver
- 13 Bolt
- 14 Bolt Handle Knob \*\*
- 15 Extractor
- 16 Extractor Collar
- 17 Firing Pin
- 18 Firing Pin Spring
- 19 Support, Firing Pin Spring
- 20 Nut, Firing Pin Spring
- 21 Cocking Piece
- 22 Pin, Firing Pin Nut
- 23 Cap
- 24 Bolt Sleeve
- 25 Disassy Catch
- 26 Disassy Catch Spring
- 27 Disassy Catch Pin
- 28 Disassy Catch Plunger

- 29 Plunger Spring
- 30 Plunger Pin
- 31 Safety
- 32 Safety Pawl
- 33 Safety Pawl Spring
- 34 Roller
- 35 Safety Pawl Pin
- 36 Sear
- 37 Sear Stop
- 38 Sear Spring
- 39 Sear Pin
- 40 Bolt Stop
- 41 Bolt Stop Spring
- 42 Safety Pin
- 43 Retaining Plate
- 44 Ejector
- 45 Ejector Pin
- 46 Ejector Spring
- 47 Ball
- 48 Holder
- 49 Trigger
- 50 Trigger Lever
- 51 Trigger Lever Pin
- 52 -
- 53 Adjusting Screw, Set Trigger
- 54 Set Trigger Lever
- 55 Spring, Set Trigger Lever

- 56 Pin
- 57 Retaining Ring
- 58 Adjusting Screw (B)
- 59 Spring, Trigger Pull
- 60 Adjusting Screw, Trigger Pull (A)
- 61 Locking Nut M4
- 62 Adjusting Screw, Trigger Overtravel (C)
- 63 Locking Nut
- 64 Nylon Pin (2x)
- 65 Trigger Mechanism
- 66 Screw
- 67 Spring Washer
- 68 Stock
- 69 Butt Plate Spacer
- 70 Butt Plate
- 71 Screw, Butt Plate
- 72 Butt Plate Plug
- 73 Swivel Wood Screw
- 74 Sling Swivel
- 75 Swivel Screw
- 76 Swivel Screw Washer
- 77 Swivel Assembly
- 78 Trigger Guard - Box Version
- 79 Box Shell
- 80 Floor Plate
- 81 Floor Plate Pin

- 82 Floor Plate Latch
- 83 Spring, Floor Plate Latch
- 84 Pin, Floor Plate Latch
- 85 Magazine Box Spring
- 86 Magazine Follower
- 87 Front Spacer
- 88 Frame Screw, Front
- 89 Rear Spacer
- 90 Frame Screw, Rear
- 106 Trigger Spring
- 107 Stay
- 108 Reinforcer Screw \*
- 109 Spring Washer \*
- 110 Washer \*
- 111 Reinforcer Nut \*
- 112 Rear Sight Base
- 113 Rear Sight Blade 200m
- 114 Rear Sight Blade 300m
- 115 Rear Sight Spring
- 116 Rear Sight Spring Screw
- 117 Rear Sight Blade Pin
- 118 Locking Screw

\* Medium 2x, Magnum 1x  
 \*\* Does not apply to Magnum

\*If part is not clickable, it is either not available or not sold separately.

